

User Guide

Envirocup Grande



LEAFIELD Recycling Products




Tools

Key as provided



Standard 18" plastic refuse sack



Quality Standards All Leafield Environmental products are certificated to BS EN ISO



PPE Always wear appropriate PPE equipment and follow safety guidelines.

Cleaning Products should be rinsed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing. Non heated pressure washer can be used at no closer the 400mm away from the unit. The Pressure should be no more than 100 Bar.



Post
Leafield Way
Leafield Industrial Estate
Corsham, Wiltshire SN13 9UD



Telephone
01225 816541
Fax
01225 816501



Email
envinfo@leafieldenv.com



Website
www.leafield-environmental.com



Unlocking



Unlock the cup bin lid



The lock barrel will pop out to show that it is in the unlocked position.



Twist the lid anti-clockwise to disengage the bayonet fitting

Removing the Lids & Liquids liners



Remove the lid and place to one side



Remove the liquids liner & empty the contents




Remove the cup lids liner and empty contents for recycling

Remove the cups



Lift out the cup stacker moulding and place to one side



As you lift out the stacking moulding the cups will remain in the plastic sack



With the stacking unit removed the cups can be collected in the plastic sack



Post
Leaffield Way
Leaffield Industrial Estate
Corsham, Wiltshire SN13 9UD



Telephone
01225 816541
Fax
01225 816501



Email
envinfo@leaffieldenv.com



Website
www.leaffield-environmental.com



Collect the Cups



Lift the back containing the cups out of the bin and put to one side for recycling

Replacing the cup holder



Note the position of the lid locating lugs on the bin body



Place a new plastic sack in the bin body



Stretch the neck of the sack over the rim of the bin body

Replacing the cup holder (Continued)



Push the inside of the bag against the internal walls of the bin to dispel any trapped air



Note the two alignment features on the cup stacking moulding



These can be found below the arrow indicators on the top of the cup stacker



Post
Leaffield Way
Leaffield Industrial Estate
Corsham, Wiltshire SN13 9UD



Telephone
01225 816541
Fax
01225 816501



Email
envinfo@leafieldenv.com



Website
www.leafield-environmental.com



Replacing the cup holder (Continued)




Photo showing cup stacker alignment recess and bin body alignment lug in line



Photos showing cup stacker in place in the bin body with screw heads aligned with arrows

Replacing the liquids liner and lids liner & Lid



Replace the empty liquids liner with the spout located in one of the 5 alignment indicators



Replace the empty lid liner




Locate the lock alignment bezel on the bin body

Replacing the Lid



Locate the lock and the bayonet feature on the lid



When replacing the lid align the lid bayonet feature with the body bayonet feature shown above



Twist the lid so that the lock aligns with the body lock alignment bezel. Push the lock body to engage lock



Post
Leaffield Way
Leaffield Industrial Estate
Corsham, Wiltshire SN13 9UD



Telephone
01225 816541
Fax
01225 816501



Email
envinfo@leaffieldenv.com



Website
www.leaffield-environmental.com

