User guidelines LINPAC Recycling bins Envirobin

Cleaning Products should be flushed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing.



Tools None



PPE Always wear appropriate PPE equipment and follow safety guidelines

Plastic materials: Mechanical properties tested to

Powder coating: BS 3900 Zinc coating: BS 1706

Manufacturing Standard (as applicable)

BS 2782 Hot dipped galvanized: BS 729

All Leafield Environmental products are

manufactured to BS EN ISO 9002.

Removing hood and liner



Grip the rim lifting it up and off the lip of the bin base

Lift rim upward clearing the bin base and place to one side

Gather liner from top of bin, lift up and empty



Removing and replacing liners





Grip wheeled liner using forward facing handle

Tilt liner away from bin body and roll free from Replace liners tilting away from bin body and bin and empty. Repeat removal process with second liner

rolling over lip on base ensuring handle is facing outwards

Locking door



Ensure both liners are flat on bin base

Push door closed

When at closed position door will drop down and engage lock automatically



post Leafield Way, Leafield Industrial Estate Corsham, Wiltshire SN13 9UD

telephone

+ 44 (0)1225 816500



facsimile + 44 (0)1225 816501



website/email www.leafield-environmental.com recycle@leafield-environmental.com

