

User guidelines

Leaffield internal recycling

Mini **Envirobin**



Cleaning Products should be flushed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing.



Manufacturing Standard (as applicable)

All Leaffield Environmental products are manufactured to BS EN ISO 9002.
 Plastic materials: Mechanical properties tested to BS 2782 Hot dipped galvanised: BS 729.
 Powder coating: BS 3900 Zinc coating: BS1706



Tools Key:



PPE Always wear appropriate PPE equipment and follow safety guidelines.

Removing lid (for non confidential options ignore steps 1 & 9)



Turn key anti clockwise to unlock lid.



Lift lid from the front end, tilting backwards to free from rear locator.



With two hands lift the lid clear of the body & put to one side.

NOTE:

Leaffield does not operate a refuse collection system. This must be arranged by the customer.



Inserting sack



4 Locate sack around the rear of the body, slide the edges of the sack into the gap in the moulding.



5 Pull the sack taut and locate around the upstand at the front of the body.




6 Sack is taut and secured in bin body.

Replacing lid



7 Locate the rear peg of the lid under the lip at the back of the body.



8 Allow the lid to drop into position ensuring the front peg locates in the body.



9 Push the lock in firmly fixing the lid in place.



post
Leaffield Way, Leaffield Industrial Estate
Corsham, Wiltshire SN13 9UD



telephone
+44(0)1225 816500



facsimile
+44(0)1225 816501



website/email
www.linpac-environmental.com
envinfo@linpac.com

